





# Internal Corner

A how-to guide to installing an internal corner.

	<p><b>Step 1</b> Adhere one of the upstands and apply contact adhesive to the remaining rubber and upstand as shown. Draw a 45-degree line from the corner outwards.</p>
	<p><b>Step 2</b> Once dry, mate the EPDM as shown, up to the line. Fold the remaining section of rubber to form a neat triangular flap that will neatly dress into the internal corner.</p>
	<p><b>Step 3</b> Apply primer with a quick scrubber pad and handle, allow to dry.</p>
	<p><b>Step 4</b> Mate the surfaces together and roller.</p>