





Butt Join

A guide to butting two pieces of adjoining Lineflex Fleece Backed EPDM membranes.

	<p>Step 1 Position the Rubber Cover sheets side by side.</p>
	<p>Step 2 Apply primer 85mm wide onto each sheet.</p>
	<p>Step 3 Position cover tape along the seam area and remove the backing paper at a 45-degree angle.</p>
	<p>Step 4 Thoroughly roller.</p>