





Internal Corner

A how-to guide to installing an internal corner.

| | |
|---|--|
|  A 3D perspective diagram of a roof internal corner. A grey EPDM membrane is partially installed, with one side already adhered to the brick wall. A white bottle of adhesive is shown on the flat surface of the membrane. A dashed line indicates the 45-degree angle to be drawn from the corner. | <p>Step 1</p> <p>Adhere one of the upstands and apply contact adhesive to the remaining rubber and upstand as shown. Draw a 45-degree line from the corner outwards.</p> |
|  A 3D perspective diagram showing the EPDM membrane being folded into the internal corner. The membrane is pulled up to the 45-degree line and then folded back down to form a neat triangular flap that fits into the corner. | <p>Step 2</p> <p>Once dry, mate the EPDM as shown, up to the line. Fold the remaining section of rubber to form a neat triangular flap that will neatly dress into the internal corner.</p> |
|  A 3D perspective diagram showing a white bucket of primer and a scrubber pad being used to apply primer to the EPDM membrane surface. The scrubber pad is shown in the corner, applying the primer to the membrane. | <p>Step 3</p> <p>Apply primer with a scrubber pad and handle, allow to dry.</p> |
|  A 3D perspective diagram showing a roller being used to mate the EPDM membrane surfaces together. The roller is shown in the corner, pressing the two sides of the membrane together. | <p>Step 4</p> <p>Mate the surfaces together and roller.</p> |