





# Onto Tiles

A how-to guide to installing Firestone RubberCover EPDM membrane onto tiles.

 <p>A 3D perspective diagram showing a grey EPDM membrane being laid over a roof of brown tiles. A dimension line indicates a 150mm overhang of the membrane onto the tiles. The background is a repeating watermark of 'AVENIR ROOFING LTD'.</p>	<p><b>Step 1</b> Allow 150mm overhang onto tiles.</p>
 <p>A 3D perspective diagram showing a dark grey lead strip being installed over the EPDM membrane. Arrows point to the lead strip being placed over the tiles and the deck. The background is a repeating watermark of 'AVENIR ROOFING LTD'.</p>	<p><b>Step 2</b> Dress lead into place 6" onto tiles, 3" onto the deck. We recommend using minimum 9" Code 4 lead cut into 1200mm lengths max.</p>
 <p>A 3D perspective diagram showing a screw being used to secure the lead strip. A circular inset shows a close-up of the screw. The background is a repeating watermark of 'AVENIR ROOFING LTD'.</p>	<p><b>Step 3</b> Fix into position using screws.</p>
 <p>A 3D perspective diagram showing a hand applying a dark liquid from a white container to the lead strip and the EPDM membrane. The background is a repeating watermark of 'AVENIR ROOFING LTD'.</p>	<p><b>Step 4</b> Apply Quick Prime plus to lead and rubber approx. 160mm wide using Quickscriber pad and handle. Allow to go touch dry.</p>



### **Step 5**

Centralize the 6" batten cover strip and carefully remove release paper applying downward pressure. Use silicone roller to seal.