


Under Tiles


A how-to guide to installing Techno EPDM membrane under tiles.

	<p>Step 1 Carefully remove tiles and battens and place to one side.</p>
	<p>Step 2 Fold the felt underlay up and tuck under existing tiles.</p>
	<p>Step 3 Apply a thin coat of contact adhesive to the rubber membrane and lay board.</p>
	<p>Step 4 Allow both surfaces to dry and, starting from the bottom, mate together, working the rubber into any angle changes.</p>



Step 5

Reinstate the felt underlay and battens over the rubber.



Step 6

Reinstall the tiles.